

**MERRILL'S**

## **BRISKET BASE FREESTALL INSTALLATION GUIDE** **Mat, Mattress or Waterbed Platform Style**

**Patent #5,975,026**

(Page 1 of 4)

**Tools:** Tape, Chalkline, Hammer Drill with 3/16" Bits, Battery, Drill with Phillips Bits No. 4 and No. 2, Welder, Impact Wrench with 9/16" and 3/4" Sockets, and Wrench set.

**Cement Contractor:** Pour Stall Platforms. Usually, set outside form and pour Curb, Sloped Platform and Flat Area for Brisket Base Plate Assembly in one pour.



**Step 1:** Measure, Chalkline or Laser, and set Base Plates  
Brisket Board Placement (recommend 66" - consult drawing for job)

